

Acel part number AC0533

Voltage & Continuity Tester


OV - 690V Indication AC/DC
Will not Trip RCDs when Connected Live to Earth
Loud Continuity Buzzer
2 Pole Phase Rotation Test
Built in Proving Check to Comply with HSE GS38,
12b

Conforms Fully to BS EN 61243-3:2014
Conforms with HSE GS38
LCD and LED Indication
Polarity Test

Single Pole Live Side Test Torch Light

IP64

Low Battery Warning
Comes with Padded Case & Belt Loop
2x AAA Batteries Supplied
CATIII 1000V, CATIV 600V
Auto Power Off



Section-AC CODE-YEAR-VERSION to go here e.g. 10-AC0123-2021-V1

